

# Cleanup

## Continuum™ Rigid Sheet

---

### Clean-up

Completion: Immediately upon completion of installation, clean sheet and remove layout marks, excess adhesive, and surface blemishes. Cured adhesive is difficult to remove. Use denatured alcohol and rub gently with a soft cloth. After adhesive is removed, wipe the area with a general purpose cleaner like fantastik®. Rinse the area with a water dampened cloth. Dry with a clean soft cloth.

- Upon Completion, remove layout marks, excess adhesive and surface blemishes.
- Cured Adhesive.
- Use denatured alcohol and gently rub.
- Follow by wiping with a cleaner like fantastik®.
- Rinse sheet with water dampened cloth.

### Maintenance

For general cleaning, use Antibacterial fantastik® All Purpose Cleaner Heavy Duty. Use a clean, lint-free cloth and wipe clean.

For tough stains, like markers, pencil, white marks, and rubber heel marks, the following was shown to be most effective: Do not use any abrasive cleaning cloths or sponges.

- Zep® Heavy Duty Citrus Degreaser
- Clorox® Clean-up with Bleach
- Antibacterial fantastik® All Purpose Cleaner Heavy Duty

1. Spray products onto sheet and wipe with a dampened cloth.
2. Repeat process if stain remains. If cleaning product residue remains, rinse with water.

Note: Any reference to a specific branded product does not constitute an endorsement by InPro Corporation.

If pressure/power washing sheets, maintain a 3ft. [1m] distance from sheet, trim pieces, and seams. Ensure pressure does not exceed 3,300 psi. DO NOT use direct, focused pressure streams over sealant joints.

### After Installation

Maintain environmentally controlled conditions after the installation. Large temperature changes can cause de-lamination.

- Maintain environmentally controlled conditions.
- Large temperature changes can cause de-lamination.

IPC.3241/REV.2