# Partition Cleaning and Care Instructions Prism™ Solid Surface

# Cleaning and Care of your Prism™ Solid Surface Partition Panels

There are two types of solid surface finishes: matte and satin. Lighter colors are finished with a matte finish, and darker colors receive a satin finish.

To prevent the build up of a film on the surface, it is very important to wipe the surface completely dry after cleaning.

#### Note:

Do not spray water directly onto wood core partitions.

# **Surfaces - Cleaning all Finishes**

## Cleaning

Spray entire surface with LYSOL Power & Free Bathroom Cleaner, wipe with a clean cloth or sponge. No rinsing required.

## **Prevent Hard Water Marks**

Rinse and wipe completely dry after cleaning. On vertical surfaces a squeegee works well.

# Removing Soap Scum, Limescale and Rust Stains

Spray entire surface with LYSOL Power & Free Bathroom Cleaner, allow product to sit for 10 minutes before wiping with a clean cloth or sponge. Repeat if necessary.

## Removing Hard Water Marks

Use Cleaner formulated for removing hard water marks, such as CLR.

## Disinfecting

Occasionally wipe surface with diluted household bleach - 1:10 (1.5 cups of bleach to 1 gallon of water, As recommended by the Centers For Disease Control and Prevention for disinfection and sterilization of surfaces)

# **Preventing Other Damage**

In most cases Prism™ Solid Surface can be repaired if damaged. Be sure to follow these guidelines to help you prevent permanent damage to your solid surface panels:

 Avoid getting strong chemicals, such as paint removers, oven cleaners, etc., on your Prism™ Solid Surface. If a spill does occur, promptly flush the surface with water to fully rinse off the chemical.

# Renewing the Finish

## Sanding:

Using a 5" or 6" random-orbital sander, move the sander in an orbital pattern, overlapping each pass by 50%. Sand slowly and evenly, keeping the micron paper clean from sanding dust (Check paper frequently).

### Matte Finish (Class A & A1)

 Use a 100 micron sanding pad to remove marks and scratches and even out the finish.
 The easily maintained matte finish is suitable for high use areas.

## Satin Finish (Class B)

- Remove marks and scratches with a 100 micron sanding pad.
- Repeat the process with a 60 micron sanding pad.
- Use a Scotch-Brite® pad (#7447 Maroon, Very Fine, 320-400 Grit) under the sanding pad to even out the finish.
- Repeat the process with a Scotch-Brite® pad (#7448 Gray, Ultra Fine, 600-800 Grit).

# **Stainless Steel Hardware Cleaning Guide**

#### Note

- Do not use cleaners containing Muriatic or Hydrochloric acid, these chemicals may damage or discolor the stainless steel finish.
- Do not use steel wool as it may leave behind steel particles which may cause rust stains.

# **Removing smudges and fingerprints**

Wipe surface with quality stainless steel cleaner/polish. Apply using a soft, non-abrasive cloth. Always follow cleaner/polish directions.

# Removing dirt and debris

Wash surface with a mild liquid soap. Apply using a soft, non-abrasive cloth. Rinse thoroughly with clean soft water. Wipe surface with stainless steel cleaner/polish.

# **Removing rust stains**

Wash surface with CLR cleaner. Use recommended solution. Apply using a soft non-abrasive sponge. Rinse thoroughly with clean soft water. Wipe surface with stainless steel cleaner/polish.

# Renewing a satin finish

Apply a stainless steel polish/cleaner using a synthetic, abrasive, pad such as a Scotch Brite® pad. Be sure to rub in the direction of the grain.

IPC.3053/REV.2



**Installation Hotline:** 866.394.6776

# Partition Cleaning and Care Instructions Prism™ Solid Surface

#### Note:

 After cleaning tough problems, let dry, and expose to air for atleast 24 hours to allow "healing" of the stainless steel surface.

# **Piano Hinge Routine Maintenance**

The piano hinge is a metal-on-metal design which requires routine maintenance in order to prevent it from squeaking or binding.

- Clean hinge to remove any dust, dirt, or debris.
- Lubricate hinge with a PTFE (Teflon) based lubricant.

#### Note:

 Do not use machine oil or liquid WD-40, these lubricants will collect dust and dirt.

### Sources for materials mentioned above:

CLR®	Local Retail
Registered trademark of Jelmar	
Clean EnCounters®	Stone Care International
Registered trademark of Stone Care International	(800) 839-1654
Scotch Brite™	Local Retail
Registered trademark of 3M Company	
Soft Scrub®	Local Retail
Registered trademark of the Dial Corporation	
Rock Doctor Granite Polish	Local Retail
Rock Doctor Products, a division of Apex Products	
LYSOL Power & Free Bathroom Cleaner	Local Retail
Registered trademark of Reckitt Benckiser, Inc	

When used properly, LYSOL Power & Free Bathroom Cleaner kills the following bacteria and viruses on hard non-porous surfaces: Salmonella enteric (Salmonella), Escherichia coli O148:H7, Pseudomonas aeroginosa, Staphylocuccus aureus (Staph), Avian Influenza AH1N1, Herpes Symplex Virus Type 1, Rhinovirus Type 37, Rotavirus WA (Source: LYSOL website)

## **Quality Assurance**

With proper care, your Prism™ Solid Surface can stay looking like new. Your Inpro® Prism™ Solid Surface Partitions carry a 5-year Limited Warranty.

